

NEHRU COLLEGE OF ENGINEERING AND RESEARCH CENTRE

(Accredited by NAAC, Approved by AICTE New Delhi, Affiliated to APJKTU)

Pampady, Thiruvilwamala(PO), Thrissur(DT), Kerala 680 588

DEPARTMENT OF MECHATRONICS



LAB WORK BOOK



MECHATRONICS LABORATORY

VISION

To mould true citizens who are millennium leaders and catalysts of change through excellence in education.

MISSION

NCERC is committed to transform itself into a center of excellence in Learning and Research in Engineering and Frontier Technology and to impart quality education to mould technically competent citizens with moral integrity, social commitment and ethical values.

We intend to facilitate our students to assimilate the latest technological know-how and to imbibe discipline, culture and spiritually, and to mould them in to technological giants, dedicated research scientists and intellectual leaders of the country who can spread the beams of light and happiness among the poor and the underprivileged.

ABOUT DEPARTMENT

- ◆ Established in: 2013
- ◆ Course offered: B.Tech Mechatronics Engineering
- ◆ Approved by AICTE New Delhi and Accredited by NAAC
- ◆ Affiliated to the University of Dr. A P J Abdul Kalam Technological University.

DEPARTMENT VISION

To develop professionally ethical and socially responsible Mechatronics engineers to serve the humanity through quality professional education.

DEPARTMENT MISSION

MD 1: The department is committed to impart the right blend of knowledge and quality education to create professionally ethical and socially responsible graduates.

MD 2: The department is committed to impart the awareness to meet the current challenges in technology.

MD 3: Establish state-of-the-art laboratories to promote practical knowledge of mechatronics to meet the needs of the society.

PROGRAMME EDUCATIONAL OBJECTIVES

PEO1: Graduates shall have the ability to work in multidisciplinary environment with good professional and commitment.

PEO2: Graduates shall have the ability to solve the complex engineering problems by applying electrical, mechanical, electronics and computer knowledge and engage in lifelong learning in their profession.

PEO3: Graduates shall have the ability to lead and contribute in a team with entrepreneur skills, professional, social and ethical responsibilities.

PEO4: Graduates shall have ability to acquire scientific and engineering fundamentals necessary for higher studies and research.

PROGRAM OUTCOMES (PO'S)

Engineering Graduates will be able to:

PO 1. Engineering knowledge: Apply the knowledge of mathematics, science, engineering fundamentals, and an engineering specialization to the solution of complex engineering problems.

PO 2. Problem analysis: Identify, formulate, review research literature, and analyze complex engineering problems reaching substantiated conclusions using first principles of mathematics, natural sciences, and engineering sciences.

PO 3. Design/development of solutions: Design solutions for complex engineering problems and design system components or processes that meet the specified needs with appropriate consideration for the public health and safety, and the cultural, societal, and environmental considerations.

PO 4. Conduct investigations of complex problems: Use research-based knowledge and research methods including design of experiments, analysis and interpretation of data, and synthesis of the information to provide valid conclusions.

PO 5. Modern tool usage: Create, select, and apply appropriate techniques, resources, and modern engineering and IT tools including prediction and modeling to complex engineering activities with an understanding of the limitations.

PO 6. The engineer and society: Apply reasoning informed by the contextual knowledge to assess societal, health, safety, legal and cultural issues and the consequent responsibilities relevant to the professional engineering practice.

PO 7. Environment and sustainability: Understand the impact of the professional engineering solutions in societal and environmental contexts, and demonstrate the knowledge of, and need for sustainable development.

PO 8. Ethics: Apply ethical principles and commit to professional ethics and responsibilities and norms of the engineering practice.

PO 9. Individual and team work: Function effectively as an individual, and as a member or leader in diverse teams, and in multidisciplinary settings.

PO 10. Communication: Communicate effectively on complex engineering activities with the engineering community and with society at large, such as, being able to comprehend and write effective reports and design documentation, make effective presentations, and give and receive clear instructions.

PO 11. Project management and finance: Demonstrate knowledge and understanding of the engineering and management principles and apply these to one's own work, as a member and leader in a team, to manage projects and in multidisciplinary environments.

PO 12. Life-long learning: Recognize the need for, and have the preparation and ability to engage in independent and life-long learning in the broadest context of technological change.

PROGRAM SPECIFIC OUTCOMES (PSO'S)

PSO 1: Design and develop Mechatronics systems to solve the complex engineering problem by integrating electronics, mechanical and control systems.

PSO 2: Apply the engineering knowledge to conduct investigations of complex engineering problem related to instrumentation, control, automation, robotics and provide solutions.

COURSE OUTCOME

C409.1	Examine various valves and cylinders used in pneumatic kits for various operations.
C409.2	Experimentally acquire the basic knowledge in assemble of electro-pneumatic kits for various operations.
C409.3	Experimentally analyze the speed control of stepper motor and servo motors, various sensors used in automotives.
C409.4	Analyze working of a pick and place robot.
C409.5	Apply the virtual instrumentation technique to analyze the operation of ADC and DAC.
C409.6	Apply the virtual instrumentation technique to analyze the operation of data acquisition and various mathematical and logical operation using Labview software and to study the automatic door opening and closing system using PLC.

CO VS PO'S AND PSO'S MAPPING

CO	PO 1	PO2	PO3	PO4	PO5	PO6	PO7	PO8	PO9	PO10	PO11	PO12	PSO 1	PSO 2
C409.1	3	2	2	2	-	-	-	-	3	-	-	3	3	3
C409.2	3	2	2	2	-	-	-	-	3	-	-	3	3	3
C409.3	3	2	2	2	-	-	-	-	3	-	-	3	3	3
C409.4	2	2	2	2	3	-	-	-	2	-	-	3	3	3
C409.5	3	2	2	2	3	-	-	-	3	-	-	3	3	3
C409.6	3	2	3	2	3	-	-	-	3	-	-	3	3	3
ATTAINMENT	2.83	2.00	2.16	2.00	2.00	0.00	0.00	0.00	3.00	0.00	0.00	3.00	3.00	3.00

Note: H-Highly correlated=3, M-Medium correlated=2, L-Less correlated=1

PREPARATION FOR THE LABORATORY SESSION
GENERAL INSTRUCTIONS TO STUDENTS

1. Read carefully and understand the description of the experiment in the lab manual. You may go to the lab at an earlier date to look at the experimental facility and understand it better. Consult the appropriate references to be completely familiar with the concepts and hardware.
2. Make sure that your observation for previous week experiment is evaluated by the faculty member and you have transferred all the contents to your record before entering to the lab/workshop.
3. At the beginning of the class, if the faculty or the instructor finds that a student is not adequately prepared, they will be marked as absent and not be allowed to perform the experiment.
4. Bring necessary material needed (writing materials, graphs, calculators, etc.) to perform the required preliminary analysis. It is a good idea to do sample calculations and as much of the analysis as possible during the session. Faculty help will be available. Errors in the procedure may thus be easily detected and rectified.
5. Please actively participate in class and don't hesitate to ask questions. Please utilize the teaching assistants fully. To encourage you to be prepared and to read the lab manual before coming to the laboratory, unannounced questions may be asked at any time during the lab.
6. Carelessness in personal conduct or in handling equipment may result in serious injury to the individual or the equipment. Do not run near moving machinery/equipment's. Always be on the alert for strange sounds. Guard against entangling clothes in moving parts of machinery.
7. Students must follow the proper dress code inside the laboratory. To protect clothing from dirt, wear a lab coat. Long hair should be tied back. Shoes covering the whole foot will have to be worn.
8. In performing the experiments, please proceed carefully to minimize any water spills, especially on the electric circuits and wire.
9. Maintain silence, order and discipline inside the lab. Don't use cell phones inside the laboratory.
10. Any injury no matter how small must be reported to the instructor immediately.

11. Check with faculty members one week before the experiment to make sure that you have the handout for that experiment and all the apparatus.

AFTER THE LABORATORY SESSION

1. Clean up your work area.
2. Check with the technician before you leave.
3. Make sure you understand what kind of report is to be prepared and due submission of record is next lab class.
4. Do sample calculations and some preliminary work to verify that the experiment was successful

MAKE-UPS AND LATE WORK

Students must participate in all laboratory exercises as scheduled. They must obtain permission from the faculty member for absence, which would be granted only under justifiable circumstances. In such an event, a student must make arrangements for a make-up laboratory, which will be scheduled when the time is available after completing one cycle. Late submission will be awarded less mark for record and internals and zero in worst cases.

LABORATORY POLICIES

1. Food, beverages & mobile phones are not allowed in the laboratory at any time.
2. Do not sit or place anything on instrument benches.
3. Organizing laboratory experiments requires the help of laboratory technicians and staff. Be punctual.

SYLLABUS

Course code	Course Name	L-T-P - Credits	Year of Introduction
MR431	Mechatronics Lab	0-0-3-1	2016
Prerequisite : Nil			
Course Objectives			
<ul style="list-style-type: none"> • To provide hands on experience on the working of hydraulic and pneumatic controls, speed control, and PID controllers • To impart proficiency in programming of robots • To impart knowledge on virtual instrumentation and vision systems 			
List of Exercises/Experiments :			
<ol style="list-style-type: none"> 1. Design and assembly of pneumatic/hydraulic kit 2. Study of different type of pneumatic and hydraulic valve. 3. Study of reciprocating movement of double acting cylinder using pneumatic direction control valve. 4. Speed control stepper and servo motor using micro processor kit. 5. Programming Robot (Pick and place robot) 6. Sensors for automotives 7. Tool condition monitoring using sensors. 8. PID Controller 9. Automatic door opening and closing 10. Virtual Instrumentation <ol style="list-style-type: none"> a. Data acquisition b. Image acquisition c. Stepper and servo control device d. Signal conditioning of strain gauge. LVDT, Thermocouple, pressure transducer, etc., 11. A/D and D/A conversion 12. Machine Vision system 13. Study of robot end effectors 			
Expected outcome.			
The students will be able to			
<ul style="list-style-type: none"> • Develop pneumatic circuits for automating various operations • Program a robot for a pick and place operation • Prescribe sensors for monitoring and control operations • Acquire knowledge on analog and digital data convertors 			

INDEX

EXP NO	EXPERIMENT NAME	PAGE NO	MARKS	SIGN
1	STUDY OF PNEUMATIC SYSTEM COMPONENTS	9		
2	ELECTRO PNEUMATIC CIRCUIT TO CONTROL THE SINGLE ACTING CYLINDER	11		
3	ELECTRO-PNEUMATIC CIRCUIT FOR EXTENSION AND RETRACTION OF DOUBLE ACTING CYLINDER.	13		
4	CONTROL THE SINGLE ACTING AND DOUBLE ACTING CYLINDERS USING PILOT VALVES	16		
5	CONTINUOUS RECIPROCATING OF SINGLE ACTING AND DOUBLE ACTING CYLINDER USING PILOT VALVES	19		
6	RUN THE STEPPER MOTOR AT DIFFERENT SPEED AND DIFFERENT DIRECTION	21		
7	RUN THE STEPPER MOTOR IN FORWARD AND REVERSE DIRECTION	25		
8	BASIC ARITHMETIC OPERATIONS	29		
9	BOOLEAN OPERATIONS	31		
10	SUM OF 'n' NATURAL NUMBERS USING WHILE LOOP	33		
11	FACTORIAL OF A GIVE NUMBER USING WHILE LOOP	35		
12	DATA ACQUISITION USING LABVIEW	38		
13	DAC-0808	41		
14	R-2R LADDER DAC	43		

15	BINARY WEIGHTED DAC	46		
16	ADC- 0808	49		
17	SENSORS FOR AUTOMOTIVES	52		
18	AUTOMATIC DOOR OPENING AND CLOSING	56		
19	P,PI,PD AND PID CONTROLLER	58		

FINAL VERIFICATION BY THE FACULTY

TOTAL MARKS:

INTERNAL EXAMINER

EXTERNAL EXAMINER

EXP NO:1

STUDY OF PNEUMATIC SYSTEM COMPONENTS

AIM:

To study the various pneumatic components used in pneumatic systems and to understand the working of them.

COMPONENTS:

Air Tank, Air compressor, Electric motor ,Air conditioners and Control valves, Actuator, Air hoses

DESCRIPTION:

1. AIR TANK

An air tank is used to store a given volume of compressed air. An air tank consists of air filter, air pressure indicator, water drainage tap. In small compressor units generally compressor is fit on the air tank.

2. AIR COMPRESSOR

An air compressor is a machine that compresses air from a low inlet pressure (usually atmospheric) to a higher desired pressure level. This is accomplished by reducing the volume of the gas. Air compressors are generally positive displacement units and are either of the reciprocating piston type or the rotary screw or rotary vane types.

3. ELECTRIC MOTOR

An electric motor is used to drive the compressor. Then the compressor compresses air from a low inlet pressure to a higher desired pressure level. This compressed air pressure is used to do the useful work.

4. AIR CONDITIONING UNIT AND CONTROL VALVES


The conditioning of air is done by the FRL unit. The filter removes the unwanted contaminants from the compressed air and the regulator is used to regulate the pressure to the required level from the higher level. The lubricator adds the lubricating oil to the air so that the air gains some lubricating properties to minimize friction during movement of components. Control components such as directional control valves, flow control valves are also used in the pneumatic circuits.

5. ACTUATORS

Compressor performs the function of adding pressure energy to the atmospheric air in the pneumatic system. Pneumatic actuators and motors do just the opposite. They extract energy from compressed air and convert into mechanical energy to perform useful work. There are three types of actuators: 1. Linear actuators (Pneumatic cylinders) 2.Rotary actuators (Air motors) and 3. Oscillators (Partial rotary movement).

6. AIR HOSES

Air hoses are used to carry the pressurized air from one location to other location. Steel, copper pipes and PU tubing are normally used air hoses.



RESULT:

INFERENCE

EXP NO: 2
ELECTRO PNEUMATIC CIRCUIT TO CONTROL THE SINGLE ACTING CYLINDER

AIM:

To construct a pneumatic circuit to control the single acting cylinder electrically using push button switch.


REQUIREMENTS:

1. Compressor,
2. FRL
3. solenoid coil
4. electrical trainer
5. single acting cylinder

PROCEDURE:

1. Draw the circuit diagram.
2. Electro controller gives - voltage to pneumatic panel.
3. Input of push button is getting from solenoid valve output.
4. Connect the air supply to FRL unit.
5. Check all the connections carefully
6. Test the circuit.
7. Observe the working of the cylinder using the 3/2 single solenoid valve.

CIRCUIT DIAGRAM



RESULT

Thus the movement of single acting cylinder was carried out using the 3/2 single solenoid valve.

EXP NO: 3
ELECTRO-PNEUMATIC CIRCUIT FOR EXTENSION AND
RETRACTION OF DOUBLE ACTING CYLINDER.

AIM:

To develop a electro-pneumatic circuit for extension and retraction of double acting cylinder.

REQUIREMENTS:

1. Double acting cylinder
2. 3/2 solenoid valve
3. 5/2 single and double solenoid valve
4. FRL unit
5. Relay
6. SPDT Switch
7. Pushbutton switch
8. Connecting tubes & wires

PROCEDURE:

A.CONTROL OF DOUBLE ACTING CYLINDER USING 3/2 SOLENOID VALVE

1. Provide power supply to the pneumatic trainer from control trainer by interfacing 24+vand-v
2. Using the SPDT switch energize the corresponding solenoid valve to get the desired movement in the cylinder.
3. Supply the Air to FRL unit.
4. Assemble all the components.

5. Check all the connections carefully.


Test the circuit. Observe the working of the cylinder using the 3/2 and 5/2 solenoid valve

B. CONTROL OF DOUBLE ACTING CYLINDER USING 5/2 DOUBLE SOLENOID VALVE


1. Draw the circuit diagram and connect the air supply to FRL unit.
2. Connect the electrical circuit from 24 dc source to ON/OFF switch.
3. Solenoids are connected to the pushbutton switch.
4. When the solenoid is given a signal solenoid are cut and the solenoids are de-energized and the DCV activated to single and double acting cylinder.
5. When off button is pressed the signal solenoid are cut and the solenoids are de-energized and the DCV comes to the original position.

CIRCUIT DIAGRAM

A.CONTROL OF DOUBLE ACTING CYLINDER USING 3/2 SOLENOID VALVE



B.CONTROL OF DOUBLE ACTING CYLINDER USING 5/2 DOUBLE SOLENOID



RESULT

INFERENCE

EXP NO: 4

CONTROL THE SINGLE ACTING AND DOUBLE ACTING CYLINDERS USING PILOT VALVES


AIM:

To actuate single and double acting cylinders in a pneumatic circuit.


APPARATUS REQUIRED:

1. Single acting cylinder
2. 3/2 push button spring return DCV
3. 3/2 single pilot valve
4. 5/2 single, double pilot DCV
5. Air service unit
6. Connecting tubes


CIRCUIT DIAGRAM-SINGLE ACTING CYLINDER



DOUBLE ACTING CYLINDER WITH 5/2 SINGLE PILOT VALVE



CIRCUIT DIAGRAM-DOUBLE ACTING CYLINDER WITH 5/2 DOUBLE PILOT



PROCEDURE:

1. The connection is made as shown in figure.
2. The pilot pressure are fed into the 3/2 direction control valve.
3. When the button is pushed the air is sent into single acting cylinder.
4. The cylinder moves in forward position.
5. When the push button is released, it retracts because of the spring.
6. Feed the air through different valves and make the cylinder to actuate.

RESULT:

INFERENCE

EXP NO:5
CONTINUOUS RECIPROCATING OF SINGLE ACTING AND DOUBLE
ACTING CYLINDER USING PILOT VALVES


AIM:

To actuate a single and double acting cylinders using pilot valves

APPARATUS REQUIRED:

1. Double acting cylinder
2. 3/2 single pilot DCV
3. 5/2 single pilot DCV
4. 5/2 double pilot DCV
5. 3/2 roller lever valves
6. FRL unit
7. Connecting tubes


CIRCUIT DIAGRAM-SINGLE ACTING CYLINDER:



PROCEDURE: SINGLE ACTING CYLINDER:

1. The circuit is given as shown in figure.
2. Connect the compressed air supply to FRL unit
3. Check the all circuit
4. Open the hand slide valve
5. Observe the working of continuous running single acting cylinder

CIRCUIT DIAGRAM-DOUBLE ACTING CYLINDER-5/2 DOUBLE PILOT VALVE



PROCEDURE: DOUBLE ACTING:

1. Draw the circuit diagram
2. connect compressor air supply to FRL unit
3. Connect any one of the outputs of FRL unit to 5/2 direction control unit port 1
4. Connect port 4 of DCV to blank end of the double acting cylinder
5. Connect the output of FRL unit to the input of two 3/2 roller lever valves to give pilot pressure for 5/2 double pilot valve
6. The output of the two roller valves are connected to the either side of the 5/2 double pilot valve properly.
7. When the FRL valve is opened the higher pressure air enters the blank end of the cylinder through DCT and the piston moves forward.
8. At the end of the forward stroke the piston rod pressures the roller valve. The output of roller valve is sent to double acting cylinder to change the position.
9. Now the high pressure air from FRL unit is sent to rod end of the double acting cylinder through the second position of the DCV the piston retracts.
10. At the end of return stroke the roller valve is pressed. The output of the roller valve is sent to dc change the piston. This is repeated until the FRL valve is closed.

RESULT:

INFERENCE

EXP NO: 6

RUN THE STEPPER MOTOR AT DIFFERENT SPEED AND DIFFERENT DIRECTION

AIM:

To run a stepper motor at different speed and different direction by using 8051 assemble language.

REQUIREMENTS:

1. Stepper Motor
2. Interface Board

PROCEDURE:

1. Switch ON the micro controller
2. Initialize the starting address
3. Enter the mnemonics code in the microcontroller
4. Reset the microcontroller
5. Execute the program

PROGRAM:

Address	Label	Instruction	Opcode
4100		ORG 4100H	ENTER
4100	START	MOV DPTR, #4500H	90 45 00
4103		MOV R0, #04	78 04
4105	J0	MOVX A, @DPTR	E0
4106		PUSH DPH	C0 83
4108		PUSH DPL	C0 82
410A		MOV DPTR, #FFCOH	90 FF
410D		MOV R2, #04H	7A 04

410F		MOV R1, #FFH	79 0F
4111	DLY 1	MOV R3, #FFH	7B 0F
4113	DLY	DJNZ R3, DLY	DB FE
4115		DJNZ R1, DLY1	D9 FA
4117		DJNZ R2, DLY1	DA F8
4119		MOV @DPTR, A	FO
411A		POP DPL	D0 82
411C		POP DPH	D0 83

411E		INC DPTR	A3
411F		DJNC R0 ,J0	D8 E4
4121		SJMP START	80 DD
4123		END	. ENTER
4500	TABLE	DB 09, 05, 06, 0A	09 05 06 0A.ENTER

RESULT

INFERENCE

EXP NO: 7

RUN THE STEPPER MOTOR IN FORWARD AND REVERSE DIRECTION

AIM:

To run a stepper motor in forward and reverse rotation using 8051 assembly language

REQUIREMENTS:

1. Stepper Motor
2. Interface Board

PROCEDURE:

1. Switch ON the micro controller
2. Initialize the starting address
3. Enter the mnemonics code in the microcontroller
4. Reset the microcontroller
5. Execute the program

PROGRAM:

Address	Label	Instruction	Opcode
4100		ORG 4100H	
4100	START:	MOV R4, #33H	7C 33
4102	L2:	DPTR, #FORWARD	90 41 44
4105		L1	12 41 1C
4108		R4, L2	DC F8

410A		DELAY	12 41 3B
410D		R4, #33H	7C 33
410F	L3:	DPTR, #REVERSE	90 41 48
4112		L1	12 41 1C
4115		R4, L3	DC F8
4117		DELAY	12 41 3B
411A		START	80 E4
411C	L1:	R0, #04H	78 04
411E	LOOP :	A,@DPTR	E0
411F		83H	C0 83
4121		82H	C0 82
4123		DPTR, #OFFCOH	90 FF C0
4126		R2, #04H	7A 04
4128	L7:	R1, #05H	79 05
412A	L6:	R3, #OFFH	7B FF
412C	L4 :	R3, L4	DB FE
412E		R1, L6	D9 FA
4130		R2, L7	DA F6
4132		@DPTR ,A	F0

4133		82H	D0 82
4135		83H	D0 83
4137		DPTR	A3
4138		R0, LOOP	D8 E4
413A			22
413B	DELAY :	R5, #01H	7D 01

413D	L9 :	R2, #05H	7A 05
413F	L8:	R2, L8	DA FE
4141		R5, L9	DD FA
4143		RET	22
4144	FORWARD :	DB 09H,05H,06H,0AH	09 05 06 0A
4148	REVERSE :	DB 0AH,06H,05H,09H	0A 06 05 09

Anticlock wise					Clock wise				
Step	A1	A2	B1	B2	Step	A1	A2	B1	B2
1	1	0	0	0	1	1	0	0	0
2	0	0	0	1	2	0	0	1	0
3	0	1	0	0	3	0	1	0	0
4	0	0	1	0	4	0	0	0	0

RESULT

Thus the program to rotate the stepper motor in forward and reverse direction was derived using 8051 assemble language and was verified.

EXP NO: 8

BASIC ARITHMETIC OPERATIONS


AIM

To perform basic arithmetic operations using Labview.


PROCEDURE

- 1: Start the Lab view and select the blank VI.
- 2: Create front and block diagram panel.
- 3: Numeric controls are given as inputs and numeric indicators are given as output they are selected by right clicking on the front panel.
- 4: Different arithmetic operators such as addition, subtraction, multiplication and division are generated in block diagram panel.
- 5: Using wiring operation inputs and outputs are connected to the respective operators in the block diagram panel.
- 6: Input values are given in the front panel and the program is executed. Hence the output is generated.

Block Diagram Panel:



FRONT PANEL



RESULT

INFERENCE

EXP NO: 9

BOOLEAN OPERATIONS


Aim:

To perform Boolean operations using Labview.


Procedure

- 1: Start the Labview and select the blank VI.
- 2: Create front and block diagram panel.
- 3: To perform Boolean operation push buttons are taken as inputs and round LED as output.
- 4: Different Boolean operations such as AND, OR, XOR, NOT, NAND are selected from the block diagram panel.
- 5: Boolean inputs and outputs are wired in the block diagram panel.
- 6: Logic values 0 & 1 are given in the front panel and the program is executed.

Block diagram



Front Panel:



Truth Table:

X1	X2	Y
0	0	0
0	1	0
1	0	0
1	1	1

X1	X2	Y
0	0	0
0	1	1
1	0	1
1	1	1

X1	X2	Y
0	0	0
0	1	1
1	0	1
1	1	0

X1	X2	Y
0	0	1
0	1	1
1	0	1
1	1	0

X	Y
0	1
1	0

RESULT

INFERENCE

EXP NO: 10

SUM OF 'n' NATURAL NUMBERS USING WHILE LOOP

AIM:


To find the sum of n natural numbers using while loop.

PROCEDURE:

- 1: Create blank VI.
- 2: Right click on the block diagram panel , select program , go to structures and select a WHILE loop
- 3: The tunnels of the border are converted to shift register.
- 4: Generate an adder and greater than equal to inside the WHILE loop .
- 5: Using wiring operation required wiring is done in the block diagram panel.
- 6: Input values are given in front panel and the output is generated.

BLOCK DIAGRAM

FRONT PANEL



Input:

count
11

Constant
0

Output:

output
66

RESULT

INFERENCE

EXP NO: 11

FACTORIAL OF A GIVE NUMBER USING WHILE LOOP

AIM:


To perform the factorial of a given number using WHILE loop.

PROCEDURE:

- 1: Create blank VI.
- 2: Right click on the block diagram panel , select program , go to structures and select a WHILE loop.
- 3: Right click on the border of the WHILE loop and select add shift register, borders are converted into shift register.
- 4: Using wiring operations required connections are given in the block diagram.
- 5: Inputs are given in the front panel and the program is executed.

Block diagram

Front panel



Input:

Input
6

constant
1

Output:

Output
720

RESULT

INFERENCE

EXP NO: 12

DATA ACQUISITION USING LABVIEW

AIM:

To gather data from thermocouple and strain gauge using labview software

EQUIPMENTS REQUIRED:

NI-DAQ hardware(cDAQ-9174), J-Type thermocouple, 4 wire strain gauge


SOFTWARE REQUIRED

Labview16

THEORY

LabVIEW is very powerful when it comes to creating DAQ applications. LabVIEW includes a set of VIs that let you configure, acquire data from, and send data to DAQ devices. Often, one device can perform a variety of functions, such as analog-to-digital (A/D) conversion, digital-to-analog (D/A) conversion, digital I/O, and counter/timer operations. Each device supports different DAQ and signal generation speeds.

The DAQ system has the following parts



The parts are:

- Physical input/output signals
- DAQ device/hardware
- Driver software
- Application software

Transducers

Data acquisition begins with the physical phenomenon to be measured. This physical phenomenon could be the temperature of a room, the intensity of a light source, the pressure inside a chamber, the force applied to an object, or many other things. An effective data acquisition system can measure all of these different phenomena. A transducer is a device that converts a physical phenomenon into a measurable electrical signal, such as voltage or current

Phenomenon	Transducer
Temperature	Thermocouple, RTD, Thermistor
Light	Photo Sensor
Sound	Microphone
Force and Pressure	Strain Gage Piezoelectric Transducer
Position and Displacement	Potentiometer, LVDT, Optical Encoder
Acceleration	Accelerometer
pH	pH Electrode

Data Acquisition Hardware

Data acquisition hardware acts as the interface between the computer and the outside world. It primarily functions as a device that digitizes incoming analog signals so that the computer can interpret them. Other data acquisition functionality includes the following:

- Analog input/output
- Digital input/output
- Counter/timers
- Multifunction - a combination of analog, digital, and counter operations on a single device

National Instruments offers several hardware platforms for data acquisition. The most readily available platform is the desktop computer.

DAQ Assistant

The DAQ Assistant, included with NI-DAQmx, is a graphical, interactive guide for configuring, testing, and acquiring measurement data. With a single click, you can even generate code based on your configuration, making it easier and faster to develop complex operations. Because DAQ Assistant is completely menu-driven, you will make fewer programming errors and drastically decrease the time from setting up your DAQ system to taking your first measurement.

PROCEDURE

- 1) Configure and interface the DAC hardware with PC
- 2) Provide proper connection of the input transducer to DAQ module
- 3) Open labVIEW software and open a new VI
- 4) In block diagram, create a while loop controlled by a stop pushbutton.
- 5) Copy DAQ Assistant icon on your Block Diagram, and a window will appear.
- 6) In this window you need to select either “Acquire Signals” (i.e., Input Signals) or “Generate Signals” (i.e., Output Signals).

Select Acquire Signals → Analog Input → Temperature (for thermocouple)/ resistance (for strain gauge)

7) In the next window you select which Analog Input you want to use. Select ai0 (Analog Input channel 0) and click Finish.

8) In the next window set input range, input type and sampling rate .

9) Click OK in the DAQ Assistant window The DAQ Assistant icon appears on the Block Diagram:



10) Wire the data output to a numeric indicator




Then numeric indicator will show, e.g., the following value:



Input sensor data will be displayed in the front panel

BLOCK DIAGRAM



RESULT

INFERENCE

EXP NO: 13
DAC-0808

AIM

To study and test DAC-0808 Circuit



APPARATUS

Digital to analog trainter kit

THEORY

The DAC0808 is an 8-bit monolithic digital-to-analog converter (DAC) featuring a full scale output current settling time of 150 ns while dissipating only 33 mW with $\pm 5V$ supplies. No reference current (IREF) trimming is required for most applications since the full scale output current is typically ± 1 LSB of $255 I_{REF}/256$. Relative accuracies of better than $\pm 0.19\%$ assure 8-bit monotonicity and linearity while zero level output current of less than $4 \mu A$ provides 8-bit zero accuracy for $I_{REF} \geq 2$ mA. The power supply currents of the DAC0808 is independent of bit codes, and exhibits essentially constant device characteristics over the entire supply voltage range.

Block and Connection Diagrams



Top View
Order Number DAC0808
See NS Package M16A or N16A

PROCEDURE

1. Connect the AC supply to the kit
2. Connect D0 to I0, D1 to I1, D2 to I2 upto D7 to I7.
3. Set the multimeter in voltmeter mode, select 20V and connect (+) to T6 and (-) to GND.
4. Set the input switches initially to 'L' Position.
5. Observe the Output at T6 on a multimeter.
6. For different combination of digital input .input note the analog output.

OBSERVATION TABLE

D7	D6	D5	D4	D3	D2	D1	D0	VOLT

RESULT

INFERENCE

EXP NO: 14
R-2R LADDER DAC


AIM

To study and test R-2R ladder DAC Circuit


APPARATUS

Digital to analog trainer kit

THEORY



The following circuit diagram shows the basic 2 bit R-2R ladder DAC circuit using op-amp. Here only two values of resistors are required i.e. R and 2R. The number of digits per binary word is assumed to be two (i.e. $n = 2$). The switch positions decides the binary word (i.e. B1 B0)



The typical value of feedback resistor is $R_f = 2R$. The resistance R is normally selected any value between $2.5 \text{ k}\Omega$ to $10 \text{ k}\Omega$.

The generalized analog output voltage equation can be given as

$$V_o = -V_R \frac{R_f}{R} \left[\frac{B_1}{2^1} + \frac{B_2}{2^2} + \frac{B_3}{2^3} + \dots + \frac{B_n}{2^n} \right]$$

$$\therefore V_o = -V_R \frac{R_f}{R \times 2^n} [B_1 2^{n-1} + B_2 2^{n-2} + B_3 2^{n-3} + \dots + B_n 2^0]$$

$$\therefore V_o = -V_R \frac{R_f}{R \times 2^n} [B_1 2^{n-1} + B_2 2^{n-2} + B_3 2^{n-3} + \dots + B_n 2^0]$$

The operation of the above ladder type DAC is explained with the binary word (B1B0= 01)

PROCEDURE

1. Connect the AC supply to the kit
2. Connect D0 to I3, D1 to I2, D2 to I1 and D3 to I0.
3. Set the multimeter in voltmeter mode, select 20V and connect (+) to T1 and (-) to GND.
4. Set the input switches initially to 'L' Position.
5. Observe the Output at T1 on a multimeter.
6. For different combination of digital input .input note the analog output.

OBSERVATION TABLE

D0	D1	D2	D3	VOLT

RESULT

INFERENCE

EXP NO: 15
BINARY WEIGHTED DAC

AIM


To study and test binary weighted DAC Circuit

APPARATUS

Digital to analog trainer kit


THEORY

The binary-weighted-resistor DAC employs the characteristics of the inverting summer Op Amp circuit. In this type of DAC, the output voltage is the inverted sum of all the input voltages. If the input resistor values are set to multiples of two: 1R, 2R and 4R, the output voltage would be equal to the sum of V_1 , $V_2/2$ and $V_3/4$. V_1 corresponds to the most significant bit (MSB) while V_3 corresponds to the least significant bit (LSB).



$$V_{out} = - \left(V_1 + \frac{V_2}{2} + \frac{V_3}{4} \right)$$

The circuit for a 4-bit DAC using binary weighted resistor network is shown below:



The binary inputs, a_i (where $i = 1, 2, 3$ and 4) have values of either 0 or 1. The value, 0, represents an open switch while 1 represents a closed switch.

The operational amplifier is used as a summing amplifier, which gives a weighted sum of the binary input based on the voltage, V_{ref} .

For a 4-bit DAC, the relationship between V_{out} and the binary input is as follows:

$$\begin{aligned} V_{OUT} &= -iR_f \\ &= - \left[V_{ref} \left(\frac{a_1}{2R} + \frac{a_2}{4R} + \frac{a_3}{8R} + \frac{a_4}{16R} \right) \right] R_f \\ &= - \frac{V_{ref} R_f}{R} \left(\frac{a_1}{2} + \frac{a_2}{4} + \frac{a_3}{8} + \frac{a_4}{16} \right) \\ &= - \frac{V_{ref} R_f}{R} \left(\frac{a_1}{2^1} + \frac{a_2}{2^2} + \frac{a_3}{2^3} + \frac{a_4}{2^4} \right) \end{aligned}$$

The negative sign associated with the analog output is due to the connection to a summing amplifier, which is a polarity-inverting amplifier. When a signal is applied to the latter type of amplifier, the polarity of the signal is reversed (i.e. a + input becomes -, or vice versa).

For a n-bit DAC, the relationship between V_{out} and the binary input is as follows:

$$V_{OUT} = - \frac{V_{ref} R_f}{R} \sum_{i=1}^n \frac{a_i}{2^i}$$

PROCEDURE

1. Connect the AC supply to the kit
2. Connect D0 to I0, D1 to I1, D2 to I2 and D3 to I3.
3. Set the multimeter in voltmeter mode, select 20V and connect (+) to T2 and (-) to GND.
4. Set the input switches initially to 'L' Position.
5. Observe the Output at T2 on a multimeter.
6. For different combination of digital input .input note the analog output.

OBSERVATION TABLE

D3	D2	D1	D0	VOLT

RESULT

INFERENCE

EXP NO –16
ADC- 0808

AIM:

To study and test ADC- 0808 circuit


APPARATUS:

Analog to digital trainer

THEORY:

The ADC0808, ADC0809 data acquisition component is a monolithic CMOS device with an 8-bit analog-to- digital converter, 8-channel multiplexer and microprocessor compatible control logic. The 8-bit A/D converter uses successive approximation as the conversion technique. The converter features a high impedance chopper stabilized comparator, a 256R voltage divider with analog switch tree and a successive approximation register. The 8-channel multiplexer can directly access any of 8-single-ended analog signals.

The device eliminates the need for external zero and full-scale adjustments. Easy interfacing to microprocessors is provided by the latched and decoded multiplexer address inputs and latched TTL TRI-STATE outputs.



PROCEDURE:

Note: Supply (+/- 12V) for Op-Amp is internally provided.

1. Connect the AC supply to the kit.
2. Connect CLK OUT to CLK
3. Connect / short SOC to EOC
4. Connect input I0 to A, I1 to B and I2 to C
5. Switch ON the power.
6. Apply analog input by connecting 0-5V to CH0
7. Select the channel CH0 by combination as explained below table 1
8. Observe the output at D7 – D0 on a CRO
9. Select the channel CH1-CH7 by the combination as explained below table 1
10. Observe the output for each channel at D7 – D0 on a CRO

Table 1

SELECTED ANALOG CHANNEL	ADDRESS LINE		
	C	B	A
CH0	L	L	L
CH1	L	L	H
CH2	L	H	L
CH3	L	H	H
CH4	H	L	L
CH5	H	L	H
CH6	H	H	L
CH7	H	H	H

OBSERVATION TABLE

VOLTS	D7	D6	D5	D4	D3	D2	D1	D0	DIGITAL O/P
0									
0.5									
1									
1.5									
2									
2.5									
3									
3.5									
4									

RESULT:

INFERENCE:

EXP NO: 17

SENSORS FOR AUTOMOTIVES

AIM:

To understand the operation of various sensors used in automotives

APPARATUS:

Vehicle speed sensor, Crankshaft Sensor, Camshaft speed sensor, Mass Airflow Sensor, Oxygen Sensor, Manifold Absolute Pressure Sensor, Throttle position sensor, Coolant temperature sensor, Electronic Control Unit (ECU), Exhaust Oxygen Sensor, Distribution pulse sensor, Knock Sensor

THEORY:

Vehicle speed sensor

A **wheel speed sensor** or **vehicle speed sensor** (VSS) is a type of tachometer. It is a sender device used for reading the speed of a vehicle's wheel rotation. It usually consists of a toothed ring and pickup.

Crankshaft Sensor

A **crank sensor** is an electronic device used in an internal combustion engine, both petrol and diesel, to monitor the position or rotational speed of the crankshaft. This information is used by engine management systems to control the fuel injection or the ignition system timing and other engine parameters. Before electronic crank sensors were available, the distributor would have to be manually adjusted to a timing mark on petrol engines.

Camshaft speed sensor

The crank sensor can be used in combination with a similar camshaft position sensor to monitor the relationship between the pistons and valves in the engine, which is particularly important in engines with variable valve timing. This method is also used to "synchronise" a four stroke engine upon starting, allowing the management system to know when to inject the fuel. It is also commonly used as the primary source for the measurement of engine speed in revolutions per minute.

Mass Airflow Sensor

A **mass (air) flow sensor** (MAF) is used to find out the mass flow rate of air entering a fuel-injected internal combustion engine. The air mass information is necessary for the engine control unit (ECU) to balance and deliver the correct fuel mass to the engine. Air changes its density as it expands and contracts with temperature and pressure. In automotive applications, air density varies with the ambient temperature, altitude and the use of forced induction, which means that mass flow sensors are more appropriate than

volumetric flow sensors for determining the quantity of intake air in each cylinder.

Oxygen Sensor

An **oxygen sensor** (or *lambda sensor*) is an electronic device that measures the proportion of oxygen (O₂) in the gas or liquid being analyzed. The most common application is to measure the exhaust gas concentration of oxygen for internal combustion engines in automobiles and other vehicles in order to calculate and, if required, dynamically adjust the air fuel ratio so that catalytic converters can work optimally, and also determine whether a catalytic converter is performing properly or not. Divers also use a similar device to measure the partial pressure of oxygen in their breathing gas.

Scientists use oxygen sensors to measure respiration or production of oxygen and use a different approach. Oxygen sensors are used in oxygen analyzers which find a lot of use in medical applications such as anesthesia monitors, respirators and oxygen concentrators.

Manifold Absolute Pressure Sensor

The **manifold absolute pressure sensor (MAP sensor)** is one of the sensors used in an internal combustion engine's electronic control system.

Engines that use a MAP sensor are typically fuel injected. The manifold absolute pressure sensor provides instantaneous manifold pressure information to the engine's electronic control unit (ECU). The data is used to calculate air density and determine the engine's air mass flow rate, which in turn determines the required fuel metering for optimum combustion (see stoichiometry) and influence the advance or retard of ignition timing. A fuel-injected engine may alternatively use a mass airflow sensor (MAF sensor) to detect the intake airflow. A typical naturally aspirated engine configuration employs one or the other, whereas forced induction engines typically use both; a MAF sensor on the intake tract pre-turbo and a MAP sensor on the charge pipe leading to the throttle body.

Manifold Air Temperature

Air Temperature Sensors are continuous function devices that change resistance inversely to temperature. They measure engine intake air temperature in the manifold, intake air duct, and air cleaner. A signal is then sent to the powertrain control module.

Throttle position sensor

A throttle position sensor (TPS) is a sensor used to monitor the throttle position of a vehicle. The sensor is usually located on the butterfly spindle/shaft so that it can directly monitor the position of the throttle. More advanced forms of the sensor are also used, for example an extra *closed throttle position sensor (CTPS)* may be employed to indicate that the throttle is completely closed. Some engine control units (ECUs) also control the

throttle position electronic throttle control (ETC) or "drive by wire" systems and if that is done the position sensor is used in a feedback loop to enable that control.

Coolant temperature sensor

The *coolant temperature sensor* is used to measure the temperature of the engine coolant of an internal combustion engine. The readings from this sensor are then fed back to the engine control unit (ECU), which uses this data to adjust the fuel injection and ignition timing. On some vehicles the sensor may also be used to switch on the electric cooling fan. The data may also be used to provide readings for a coolant temperature gauge on the dashboard.

Exhaust Oxygen Sensor

The *exhaust oxygen sensor* includes a sensing portion that is exposed to the exhaust gas stream to detect residual oxygen in the exhaust gas and transmit the data to the control unit. A control unit fine-tunes the electric pulses transmitted to the fuel injectors. It includes a zirconia ceramic tube that is covered by a louvred metal shroud to protect it from breaking. A wire contacts the inner surface of the tube through a spring and an electrode bush.

Distribution pulse sensor

On newer vehicles, a coil pack replaces the distributor. It is an electronically controlled pack of ignition coils regulated by the car's computer and is used to create the spark for each engine cylinder's spark plug. Generally speaking, coil packs are much more reliable than distributors, because there are no moving parts and because they fire much less often than a distributor. Coil packs usually create a better spark, which in turn produces better combustion and horsepower in a car's engine.

Knock Sensor

This sensor creates a voltage signal based on the vibrations caused by detonation. The computer uses this signal to retard timing when spark knock occurs. The Knock sensor is typically located in the lower engine block, cylinder head or intake manifold.

Electronic Control Unit (ECU)

Electronic Control Unit (ECU) is any embedded system that controls one or more of the electrical system or subsystems in a transport vehicle.

Types of ECU include Electronic/engine Control Module (ECM), Powertrain Control Module (PCM), Transmission Control Module (TCM), Brake Control Module (BCM or EBCM), Central Control Module (CCM), Central Timing Module (CTM), General Electronic Module (GEM), Body Control Module (BCM), Suspension Control Module (SCM), control unit, or control module. Taken together, these systems are sometimes

referred to as the car's computer (Technically there is no single computer but multiple ones.) Sometimes one assembly incorporates several of the individual control modules (PCM is often both engine and transmission).



RESULT

INFERENCE

EXP NO: 18
AUTOMATIC DOOR OPENING AND CLOSING


AIM

To simulate a automatic door opening and closing system using PLC

APPARATUS:

- Sciencetech 2400I Universal PLC Platform
- Ethernet Cable
- Mains cord

THEORY



1. When someone enters the infrared sensing field, opening motor starts working to open the door automatically till the door touches the opening limit switch
2. If the door touches the opening limit switch for 7 sec and nobody enters the sensing field, the closing motor starts working to close the door automatically till the closing limit switch touched together.
3. Stop the closing action immediately if someone enters the sensing field during the door closing process.

PLC PROGRAMMIG

Number of PLC Inputs Required

X0 - X0 = ON when someone enters the sensing field.

X1 - Closing limit switch. X1 = ON when 2 switches touched together.

X2 - Opening limit switch. X2 = ON when the door touched the switches.


Number of PLC Outputs Required

Y0 -Opening motor

Y1 - Closing motor

Number of PLC Timers Required

T0 - 7 sec timer. Time base: 100ms



PLC Ladder Program for Automatic Door open Close

PROCEDURE

1. Connect mains cord to mains socket of **Sciencetech 2400L**.
3. Connect the water control trainer to the PLC board.
3. Turn the Rocker switch (Power switch) in ON position.
4. Connect Serial Ethernet Cable between PLC and PC.
5. Open “**RSLogix Micro Starter**” software.
6. Create Ladder Logic Program
7. Simulate and Test Ladder Logic Program
8. Transfer Ladder Logic Program.
9. Then put the PLC in RUN mode.

RESULT

INFERENCE

EXP NO: 19
P, PI, PD AND PID CONTROLLER

Aim:

To obtain step response of the given system and evaluate the effect P,PD,PI and PID controllers.

APPARATUS:

Software: MATLAB

THEORY:

PID controllers are commercially successful and widely used as controllers in industries. For example, in a typical paper mill there may be about 1500 controllers and out of these 90 percent would be PID controllers. The PID controller consists of a proportional mode, an Integral mode and a Derivative mode. The first letters of these modes make up the name PID controller. Depending upon the application one or more combinations of these modes are used. For example, in a liquid control system where we want zero steady state error, a PI controller can be used and in a temperature control system where zero steady state error is not specified, a simple P controller can be used.

PROCEDURE:

- 1) Consider the open loop transfer function

$$G(s) = \frac{1}{0.5S^2 + S + 4}$$

- 2) Write the program using matlab to simulate step response of the given System.
- 3) Evaluate the effect of P,PI,PD and PID controllers


PROGRAM

%Program to observe the effect P,PD,PI and PID controllers

```
num=[1];
den=[0.5 1 4];
sys1=tf(num,den);
f=feedback(sys1,1);
f1=step(f);
subplot(2,3,1);plot(f1);
title('Step response of given system')
% Proportional controller
kp=10;
numP=kp*num;
sys=tf(numP,den);
G=feedback(sys,1)
```

```
m=step(G);
subplot(2,3,2);plot(m);
title('Proportional control Kp=10')
k=dcgain(G)
essP=1/(1+k)
% PD controler
Kd=10;
numc=[Kd*kp kp];
nr=conv(numc,num);
sys1=tf(nr,den);
G1=feedback(sys1,1)
m=step(G1);
subplot(2,3,3);plot(m);
title('PD control Kp=10 and Kd=10')
%PI controller
ki=10;
numI=[kp ki*kp];
denI=[1 0];
dr=conv(denI,den);
sys2=tf(numI,dr)
G2=feedback(sys2,1);
m=step(G2);
subplot(2,3,4);plot(m);
k=dcgain(G2)
essPI=1/(1+k)
title('PI control Kp=10 and Ki=10')
%PID controller
nr1=conv(numc,[1 ki]);
sys3=tf(nr1,dr);
G3=feedback(sys3,1);
m=step(G3);
subplot(2,3,5);plot(m);
k=dcgain(G3)
essPID=1/(1+k)
title('PID control Kp=10,Ki=10 & kd=10')
```

Graph:



RESULT

INFERENCE